

Water pressure from faucet is low or flow is blocked.

Solution: Replace the aerator.

Instructions

Tools Required: Pliers

1. Remove old aerator with pliers, being careful not to grip too tightly.
2. Check faucet for any washers that may be caught up inside.
3. Install new aerator by hand, turning clockwise.
4. Turn on water. If leak occurs, tighten with pliers.

Instrucciones

Herramientas necesarias: Pinzas

1. Retire el aireador anterior con pinzas, teniendo cuidado de no apretar demasiado.
2. Verifique que no quede ninguna arandela en el interior del grifo.
3. Instale el nuevo aireador a mano, girando en el sentido de las agujas del reloj.
4. Encienda el agua. En caso de filtraciones, ajuste el aireador con pinzas.

