



SEATS & SPRINGS FOR DELTA®

Instructions

Tools Required: Adjustable Wrench, Screwdriver, Allen Wrench

1. Turn off water supply to faucet.
2. Using Allen wrench, unthread Set Screw (B), and then pull off Handle (A).
3. Unthread and remove Cap Assembly (C).
4. Remove Ball and Cam Assembly (D) by pulling up on Ball Stem.
5. Remove old rubber Seats (E) and Springs and discard. Replace with new Seats and Springs (E).
6. Reassemble Faucet in reverse order. Make sure that slot in side of Ball is inserted over pin inside body and that lug on side of Cam (F) inserted into slot on side of body. Tighten Cap (C) securely.
7. Turn on water supply to Faucet. Check for leaks.

Instrucciones

Herramientas requeridas: llave regulable, destornillador, llave hexagonal

1. Corte el suministro de agua al grifo.
2. Usando la llave hexagonal desenrosque parcialmente el tornillo de presión (B). Luego retire la manija (A).
3. Desenrosque y retire el casquete (C).
4. Retire el juego de bola y tope (D) tirando el vástago de la bola hacia arriba.
5. Retire los asientos de hule (E) y resortes desgastados y descártelos. Reemplácelos con nuevos asientos y resortes.
6. Vuelva a montar la grifo en el orden inverso. Asegúrese de que la ranura en el costado de la bola esté insertada sobre la chaveta dentro del cuerpo y que el adaptador en el costado del tope esté insertado en la ranura en el costado del cuerpo. Ajuste el casquete (C) firmemente.
7. Conecte el suministro de agua al grifo. Revise si hay fugas.

