



Visit
DANCO.COM
for Easy D.I.Y. Solutions

WRENCH FOR INSINKERATOR®

LLAVE PARA INSINKERATOR®

Instructions

Tools Required: None

1. Turn off disposal and the cold water supply.
2. Insert end of wrench into the hole in the bottom of the disposal.
3. Move wrench back and forth until it freely makes one complete turn.
4. Use tongs or similar tool to remove object causing the jam.
5. Remove wrench. Wait 3 to 5 minutes for motor to cool.
6. Turn on the water supply and then push restart button.

Instrucciones

Herramientas necesarias: ninguna

1. Apagar la unidad y la agua fría.
2. Inserte la punta de la llave en el agujer an el fondo de la unidad.
3. Mueva la llave hacia adelante y hacia atrás hasta que hace librement una vuelta completa.
4. Utillice pinzas o herramienta similar para quitar el objeto que causa el atasco.
5. Quite la llave, espere 3 a 5 minutos para que el motor refesque.
6. Conecte el suministro de agua y empuje el botón del retanzar.

©2022 Manufactured for
Danco, Inc., Irving, TX 75062
88993