



INSTALLATION INSTRUCTIONS FOR FAUCET REPAIR KIT DELTA® & PEERLESS®

Visit
DANCO.COM
for Easy D.I.Y. Solutions

Instructions

Tools Required: Adjustable Wrench, Screwdriver, Allen Wrench

1. Turn off water supply to faucet.
2. Using allen wrench, partly unthread Set Screw (B), and then pull off Handle (A).
3. Unthread and remove Cap Assembly (C).
4. Remove ball and cam assembly (D) by pulling up on ball Stem (E).
5. Lift rubber seats and springs (F) out of pockets in Faucet Body (G) to check Spray Diverter (H) and body O rings.
6. Remove and clean spray diverter unit (H). If spray diverter is worn, replace with Danco STK/No. 80092 spray diverter.
7. Reassemble faucet in reverse order, using new replacement parts. Make sure that slot in side of ball is inserted over pin inside body and that lug on side of cam is inserted into slot on side of body. Tighten Cap (C) securely.
8. Turn on water supply to faucet. Check for leaks.

Instrucciones

Herramientas requeridas: llave regulable, destornillador, llave hexagonal

1. Corte el suministro de agua al grifo.
2. Usando la llave hexagonal desenrosque parcialmente el tornillo de presión (B). Luego retire la manija (A).
3. Desenrosque y retire el casquete (C).
4. Retire el juego de bola y tope (D) tirando el vástago de la bola (E) hacia arriba.
5. Levante los asientos y resortes de goma (F) retirándolos de las cámaras de las cámaras del cuerpo del grifo (G) para revisar el derivador-rociodor (H) y los anillos en "O" en el cuerpo.
6. Retire y limpie el derivador-rociodor (H). Si el derivador-rociodor está desgastado, sustitúyalo por el derivador-rociodor Danco # 800092.
7. Vuelva a armar la llave en el orden inverso, usando la nueva piezas de repuesto. Asegúrese de que la ranura en el costado de la bola esté insertada sobre la chaveta dentro del cuerpo y que el adaptador en el costado del tope esté insertado en la ranura en el costado del cuerpo. Ajuste el casquete (C) firmemente.
8. Conecte el suministro de agua al grifo. Revise si hay fugas.

